
Body-Solid





BODY-SOLID,Inc. 1900 S. Des Plaines Ave. Forest Park, IL 60130 USA Phone:(708)427-3555 Fax:(708)427-3556 www.bodysolid.com

DLAT.2 OWNER'S MANUAL

Warning, Safety & Maintenance

Be sure that all users carefully read and understand all warning, safety and maintenance labels on the machine before each use. Failure to do so may result in death or serious injury.

It is imperative that you retain your Owner's Manual and be sure all warning labels are legible and intact. Replacement Owner's Manuals and warning labels are available from your local Body-Solid dealer.

If you have any questions about the operation, set up or maintenance of this machine please call our customer service department at 1 (800) 556-3113.

THERE IS A RISK ASSUMED BY INDIVIDUALS WHO USE THIS TYPE OF EQUIPMENT. TO MINIMIZE RISK, YOU MUST FOLLOW THESE RULES:

- 1. Inspect equipment before each workout. Check that all nuts, bolts, screws and pop pins are in place and fully tightened. Also, before use, check cables for signs of wear. Replace all worn parts immediately. Never use machine if any parts are damaged or missing. FAILURE TO FOLLOW THESE RULES MAY RESULT IN SERIOUS INJURY.
- Keep clear of the cables and all moving parts when the machine is in use.
 Always make sure all Snap Links are closed when doing any cable/pulley/strap exercises.
- Exercise with care. Perform your exercises at a smooth moderate pace; never perform jerky or uncoordinated movements that may cause injury. It is recommended that you should workout with a training partner.
- Do not allow children or minors to play on or around this equipment. If unsure of proper use of equipment, call your local Body-Solid distributor or the Body-Solid customer service department at 1-800-556-3113.
- WARNING: Consult your physician before starting your exercise program. For your own safety, do not begin any exercise program without proper instruction. RAL8-6-03 WC-54

Safety and Maintenance of Cables

IMPORTANT: Cables are responsibility to prevent unexpected breakage. Cable inspection should be performed daily. Inspect all cables, the nylon coating on all cables, and the area near the fitting at each end of each cable Replace any damaged or worn cable immediately. or worn cables are replaced. Using or allowing a machine to be used with a suspect cable can Owner's Manual for more

For Body-Solid Customer Service Call 1-800-556-3113

information.

Check the function and integrity of the following components. K As noted, Inspect equipment before each workout. Replace all damaged, broken or worn components immediately. L Υ Y Cables: Check tension, end fittings, and coating Check that locking nut at weight stack is tight Upholstery: Wipe down and dry Clean and condition Wipe down and dry Frame: Polish / Wax Chrome: Wipe down and dry Polish / Lubricate Nuts / Bolts / Fasteners: Tighten and / or adjust as needed Guide Rods: Lubricate and clean Linear Rods: Lubricate and clean Seat Sleeves: Lubricate and clean Adjustments / Locking Pins / Tightening Knobs Weight Stack Pins Warning Instruction Labels Springs / Pop Pins Anti Skid Surfaces Hand Grips/Rollers

For Body-Solid Customer Service Call 1-800-556-3113

D E

A E

Important Safety Instructions

Before beginning any fitness program, you should obtain a complete physical examination from your physician.

Il est conseille de subir un examen medical complet avant d'entreprendre tout programme d'exercise. Si vous avez des etourdissements ou des faiblesses, arretez les exercices immediatement.

Antes de comenzar cualquier programma de ejercicios, deberias tener un examen isico con su doctor.

When using exercise equipment, you should always take basic precautions, including the following:

- Read all instructions before using your machine.
 These instructions are written to ensure your safety and to protect the unit.
- Do not remove any safety labels from the machine.
- O Do not allow children on or near the equipment.
- O Use the equipment only for its intended purpose as described in this guide. Do not use accessory attachments that are not recommended by the manufacturer. Such attachments might cause injuries.
- Wear proper exercise clothing and shoes for your workout, no loose clothing.
- Keep hands, limbs, loose clothing, and long hair well out of the way of all moving parts.
- O Use care when getting on or off the unit.
- O Do not overexert yourself or work to exhaustion.
- If you feel any pain or abnormal symptoms, stop your workout immediately and consult your physician.
- Never operate unit when it has been dropped or damaged. Return the equipment to a service center for examination and repair.
- Never drop or insert objects into any opening in the equipment.
- O IMPORTANT: Cables are wear items. It is your responsibility to prevent unexpected breakage. Cable inspection should be performed daily. Inspect all cables, and the area near the fitting at each end of each cable. Replace any damaged or worn cable immediately. Do not allow the machine to be used until these are replaced.
- O Do not use the equipment outdoors or near water.

Personal Safety During Assembly

- O Before beginning assembly, please take the time to read the instructions thoroughly.
- O Read each step in the assembly instructions and follow the steps in sequence. Do not skip ahead. If you skip ahead, you may learn later that you have to disassemble components and that you may have damaged the equipment.
- Assemble and operate your machine on a solid, level surface. Locate the unit a few feet from the walls or furniture to provide easy access.

Your machine is designed for your enjoyment. By following these precautions and using common sense, you will have many safe and pleasurable hours of healthful exercise.

After assembly, you should check all functions to ensure correct operation. If you experience problems, first recheck the assembly instructions to locate any possible errors made during assembly. If you are unable to correct the problem, call the dealer from whom you purchased the machine or call **1-800-556-3113** for the dealer nearest you.

Obtaining Service

Please use your Owner's Manual to make sure that all parts have been included in your shipment. When ordering parts, you must use the part number and description from your Owner's Manual. Use only Body-Solid replacement parts when servicing this machine. Failure to do so will void your warranty and could result in personal injury.

For information about product operation or service, check out the official Body-Solid website at www.bodysolid.com or contact an authorized Body-Solid dealer or a Body-Solid factory-authorized service company or contact Body-Solid customer service at one of the following:

Toll Free: 1-800-556-3113
Phone: 1-708-427-3555
Fax: 1-708-427-3556
Hours: M-F 8:30-5:00 CST
E-Mail: service@bodysolid.com


Or write to: Body-Solid, Inc.


Service Department 1900 S. Des Plaines Ave. Forest Park, IL 60130 USA

Retain this Owner's Manual for future reference. If you need to order replacement parts please be prepared to provide the following information when contacting us so that we can assist you better.


- 1. Model Number
- 2. Proof of Purchase
- 3. Place of Purchase
- 4. Serial Number (S/N)
- 5. Part # and Description

HARDWARE ILLUSTRATION






HARDWARE ILLUSTRATION






(A6)HEX BOLT 1/2"x5 3/4"L PARTIAL THREAD QTY.1






(A9)HEX BOLT 5/16"x3 1/4"L PARTIAL THREAD QTY.2







(A22)HEX BOLT M8x55L PARTIAL THREAD QTY.1



HARDWARE ILLUSTRATION CONNECT DGYM



FRAME HARDWARE ILLUSTRATION





(A13)HEX BOLT 1/2"x2 1/4"L PARTIAL THREAD QTY.1






(A15) ROUND ALLEN HEAD 3/8"X2"L PARTIAL THREAD QTY.1

Optional Purchase








(A14)HEX BOLT M4X65L"L PARTIAL THREAD QTY.2

TOP CAP(9211-111)










TOP CAP(9211-119)

"M4X65 ROUND BOLT" and "M4 WASHER" is used to assemble with 9211-111 and 9211-119 TOP CAP






(A16)ELASTIC BOLT QTY.1



(A17)10LB PIN (8250-071) QTY.1






(A19)ROUND ALLEN HEAD M6X20L PARTIAL THREAD QTY.24






(A20)ROUND ALLEN HEAD 5/32"X1/4"L PARTIAL THREAD QTY.4



HARDWARE ILLUSTRATION









(B2)NYLON LOCK NUT 1/2" QTY.10

(

(C5)5/16"(I.D.)FLAT WASHER Ø24 QTY.4











(B7)NYLON LOCK NUT M8 QTY.1

(C6)5/16" SPRING WASHER QTY.2





(C13)1/2"(I.D.)FLAT WASHER Ø25 QTY.4




(C3)1/2"(I.D.)FLAT WASHER Ø34 QTY.17





(C4)3/8"(I.D.)FLAT WASHER Ø19 QTY.2





FRAME HARDWARE ILLUSTRATION





(B5)NYLON LOCK NUT 1/2" QTY.1





(C8)1/2"(I.D.)FLAT WASHER Ø25 QTY.2






(C9)3/8" SPRING WASHER QTY.1






(C11)M6(I.D.)FLAT WASHER Ø13 QTY.24



Selector Rod HARDWARE ILLUSTRATION





(A22) ROUND ALLEN HEAD M10X30L PARTIAL THREAD QTY.1




(A23)FIRM SHEATH(8890-046) QTY.1





(B6)NYLON LOCK NUT M10 QTY.1




HARDWARE ILLUSTRATION

D2 D3 D4 D5 D6 D7 D8 D9 D1 D1 D1 D1	2.Ø3/4"X45L STE 3.Ø1" SHAFT CO 4.Ø8 SPRING SN 5.Ø1" END CAP(9 6.Ø60 END CAP(9 7.50X100(40X80) 8.58X116X2.5T FO 9.COVER(9211-1 0.58X116 END CO 1.40X80 END CO 1.40X80 END CO 2. 3" Nylon Wash 3. Ø1"x2.5t Rour 4.Ø3/4" SHAFT (1 5.Ø2 1/2"X19.2X 6.95X140L RUBI	EEL BUSHING (81 EEL BUSHING (81 LLAR(8130-024) AP LINK(8810-00) 2211-016)	10-067) 1) 6(9211-107) 08) 021) OUNT(9310-010)	[8PCS][2PCS][2PCS][2PCS][2PCS][2PCS][2PCS][2PCS][2PCS][2PCS][2PCS][2PCS][2PCS][2PCS][2PCS]
D1	D2	D3	D4	D5
D6	D7	D8	D9	D10
D11	D12	D1	3	D14
D15	D16	6	D17	0


HARDWARE ILLUSTRATION

D18.Ø117 PULLEY(9213-010B)	[8PCS]
D19.TOP PLATE(8400-006)	
D21.1975mm STEEEL CABLE(FDLATA)	[1PCS]
D22.3250mm STEEL CABLE(FDLATB)	[1PCS]
D23.DLAT For DGYM Steel Cable(FDLATC)	
D24.150X250L RUBBER PAD(9310-036)	[2PCS]
D25.WEIGHT SELECTOR BAR(8210-042B)	[1PCS]



DLAT.2-102017

Page 3




PARTS ILLUSTRATION SHEET

M[1PCS] 8343-146 N[1PCS] 8343-147 O[2PCS] 8343-140 P[1PCS] 8290-001











Q[1PCS] 9121-054




R[2PCS] 9161-021 Ø150X250L





FRAME PARTS ILLUSTRATION SHEET




DLAT.2-082010 Page 6












DLAT.2-042008 Page 8



DLAT single weight stack assembly instructions





AA

 $\mathsf{A}\mathsf{A}$

AΑ


C11x24

A19x24

D14

AA

W



W

AA -

D19

AA -


AA 、





D15


Н


D15
















DLAT ASSEMBLY INSTRUCTIONS Above shows STEP 9 assembled and completed D3 D12 D12 -5/16"X5/16" SCREW D5 D12 D5 R D12 D3 C5 5/16"X5/16" SCREW-C6 C5 Α9 C6 Α9 DLAT.2-082010 Page 15





DLAT.2-082010 Page 16

DLAT ASSEMBLY INSTRUCTIONS Cable to match illustration D23 assemble direction D21 (C)= assemble direction CABLE FOR DGYM ONLY -D21 D23-Ø10 cable wire head A23 В6 A22 Selector Rod **DETAIL VIEW** Page 17.1 DLAT.2-042008

DLAT ASSEMBLY INSTRUCTIONS Above shows STEP 11 assembled and completed A21x2 C12x2 D18 C1x2 A10x2 B1x2 C1x2/ C3x2 B2x2 A1x2 C3x2 B1x2 C1x2 C1x2 Detial A10x2 **DGYM** D1 **DLAT** A11 C1 1/2" WASHER X2 -1/2"X1 1/4" HEX BOLT X2 DLAT.2-102016 Page 17


DLAT ASSEMBLY INSTRUCTIONS [F] DFC DGYM

DLAT.2-042008 Page 18

ASSEMBLY INSTRUCTIONS

Anti-cable Break Up Supplement Page

BA[2PCS] 8331-015



DF-042017 Page